


# Installation Instructions

## Wi-Fi Dimmer

CEN1D350W

The INT1D350W is a dimmer with Wi-Fi capability. You can control your LED lights manually via the button on your Dimmer, or wirelessly via your smart device.


**IMPORTANT:** This product only works with compatible dimmable LED lights.




### Features

- Dimmer uses direct L-N connections
- In-built On/Off button
- Wi-Fi connectivity (2.4GHz Wi-Fi only)
- Remote control via App on iOS or Android smart devices
- 7-day On/Off Timer
- Brightness control (requires compatible dimmable bulbs)
- Device firmware - wireless updates via App

### Wiring diagram



### Dimensions (mm)



### Technical data

<b>Rated supply voltage</b>	220-240V~ 50/60Hz
<b>Rated load (Resistive)</b>	2 - 350W
<b>LED Load</b>	2 - 200W
<b>Dimming method</b>	Trailing Edge
<b>Dimming range</b>	1%-100% (for compatible dimmable LED lights)
<b>Wireless mode</b>	Wi-Fi
<b>Operating frequency</b>	2.4GHz
<b>Dimensions</b>	40 x 22.5 x 48.7mm
<b>Weight</b>	35g
<b>Operating temperature</b>	-20~40°C

### Installation

1. Disconnect power
2. Remove wall plate
3. Install the Wi-Fi Dimmer into the wall plate
4. Connect the Dimmer as shown in wiring diagram
5. Re-install wall plate
6. Reconnect power

### Operating Instructions

The Wi-Fi dimmer is controlled by its single On/Off button:

- \* Short Press once to alternately turn the Dimmer On or Off.
- \* The Initial Brightness setting is recalled from its last brightness setting.

In addition, while the light is On,

1. Long Press alternately: Dims or brightens the light.
  2. Short Press twice quickly: Brighten to maximum brightness.
  3. Short Press five times quickly: Records the current brightness as the new Minimum Brightness. The LED blinks five times as confirmation.
- Tip:** Do not execute this function while the light is very bright. Otherwise, the dimming control will appear to fail, due to the small dimming range. If required, perform the next function to reset the dimming range.
4. Short Press seven times quickly: Resets the default Minimum Brightness setting. And clears the Initial Brightness setting. LED blinks 7-times as confirmation.
  5. Short Press nine times quickly: Restores Dimmer to Factory Default settings. LED will blink continuously, ready to pair with App (in EZ-mode).

### Warning

- \* Turn off the 240VAC mains supply before installation.
- \* Do not install the product behind metal objects, such as refrigerators, air-conditioners, etc., which will affect wireless signal transmission.
- \* Using the product in an environment with elevated temperatures may limit the maximum output power.
- \* Communication range will be greatly reduced by any obstacles to Wi-Fi signals, eg. walls and building material.
- \* Maximum LED load may vary due to LED load type and internal technology of attached dimmable LED light.

### App Installation

Search "PSA Centrii" in your App Store

Apple: Requires iOS 9.0 or later.

Android: Requires Android 4.4 or later



#### PSA Centrii App

Free app provided,  
support remote viewing  
on iOS or Android



### Register the PSA Centrii App

Open the PSA Centrii app.

For new users, tap "Register" to create a new login account.

For existing users, login with your registered email and password.

### Configure your PSA Centrii App

#### Setting up your home

You can setup multiple homes or locations. Using the PSA Centrii App, tap "Me >>> Home Management" to create a new Home, or to modify details of a Home.

### Add Your Wi-Fi Switch to your App

1. Power on the Wi-Fi Dimmer.
2. Wait until its LED is blinking rapidly.  
Otherwise, press its On/Off button 9-times quickly.
3. Open the PSA Centrii App. On the main screen, either tap 'Add device' or '+' icon.
4. Tap "Power" category in the left column. Tap "Dimmer (Wi-Fi)"
5. Enter your 2.4GHz Wi-Fi login details. Tap "Next" to continue.
6. Tap the top right corner to select "EZMode".  
Tap "Confirmed LED is blinking rapidly". Then tap "Next".
7. The App will then search for the Wi-Fi Dimmer.  
Once the product is added successfully, tap "Done" to finish.  
**Tip:** Tap the Pen icon to change the device name.
8. Your Wi-Fi Dimmer can now be controlled by the PSA Centrii App.