



## Setup Intrusion Detection on Centrii NVR

Method: Motion detection is off and Intrusion detection is on

1. Log into the NVR by double right clicking anywhere on the screen.



2. Enter your "admin" password then select "Login"







## Setup Intrusion Detection on Centrii NVR

Method: Motion detection is off and Intrusion detection is on


3. You may be asked for your login draw pattern if enabled.



4. Click on the "X" in the top right-hand corner to close the wizard



5. Select "OK" to exit the Wizard







## Setup Intrusion Detection on Centrii NVR

Method: Motion detection is off and Intrusion detection is on

6. Your "System Menu" will appear (showing Channel, Record, Network, Alarm, and System sections)




7. Look at the "Alarm" section and select "Intelligent Analysis"




# Setup Intrusion Detection on Centrii NVR

Method: Motion detection is off and Intrusion detection is on

8. Select the desired camera channel and Enable "Human Detection," then click "Apply"



9. Select "Detection Area" then draw a shape in the camera view to set your target location. This shape can have a maximum of 8 corners and you can have a maximum of 4 shapes.





## Setup Intrusion Detection on Centrii NVR

Method: Motion detection is off and Intrusion detection is on

10. To draw a shape, left click on your mouse to create a corner, and when on the last leg, right click the mouse to automatically connect the last/first corner.

